

QUICK START GUIDE: Battery Pack

This guide is meant to serve as a quick reference for using the optional battery pack. It is for your convenience, full instructions on changing batteries can be found in the manual provided with the pump.



1. The battery provided must only be used as an external battery
2. Always keep dry and clean
3. Use appropriate power lead to connect the battery to either the Advanced Peristaltic Pump or the Geocontrol Pro.
4. To charge the battery, you need the charging adapter that comes with both the Geocontrol Pro and the Advanced Peristaltic Pump
5. This battery will take approximately 8 hours to charge from a completely discharged state.