


QUICK START GUIDE: YSI EXO Water Quality Logger

This guide serves as a quick reference for operating the EXO Logger. It is for your convenience & not intended to replace the full-length manual where additional information may be found.

1. Fit suspension cord securely to the EXO Logger ensuring there is no possibility of detachment. If a full cable is being used carefully attach the wet-mateable connectors and screw-up the collar & slide cable hang so weight is taken off of the wired connection.
2. Remove the calibration & storage cup by unscrewing top ring anti-clockwise one turn & sliding off. Discard the old tap water.
3. Carefully & slowly lower the Logger to required height in the well. Logging will start at the pre-programmed time.
4. When logging is completed or the recommended monthly battery change is up, carefully lift the unit from the well.
5. When the unit is not in use please rinse probes & fill bottom inch of calibration cup with tap water & fit by sliding over & screwing top ring clockwise. Deionised water should never be used for storage.



Monthly recommended battery change

1. Grasp EXO labelled section of Logger & firmly twist the blue section anti-clockwise.
2. Slide off the blue cover to reveal the 2 x Dcell batteries. Replace the batteries noting polarity!
3. Carefully inspect o-ring ensuring no debris is present. Use cryptox grease very sparingly on o- rings if required.
4. Refit blue cover & screw clockwise. Tighten unit firmly, but not over-tight.
5. The unit will continue to log after replacing battery.
6. The monthly battery change is also a good time to check probes for debris & deposits.

Reprogramming

If a reprogram is required please contact Van Walt Ltd for assistance & training.



Scan to download the video