



FACT SHEET

Van Veen Grab

An easy to use surface sampler for river and lake beds, large sumps.



Disturbed samples of sludges and sediments

Advantages

- Easy to use and clean
- Quick identification of sample type
- Inert stainless steel construction
- Can be operated from a bridge, raft or boat.

Disadvantages

- Debris and pebbles in the sediment may affect sample retention
- Uneven sample sizes
- Some deviation from the sample site if strong currents present.

Accessories

- Cable, if required.

Specifications

- 1/2 litre.

Alternatives

For disturbed samples an Ekman Sampler and for undisturbed samples a Multisampler or Beeker Sampler can be used.