



# FACT SHEET

## Van Veen Grab

An easy to use surface sampler for river and lake beds, large sumps.



### Disturbed samples of sludges and sediments

#### Advantages

- Easy to use and clean
- Quick identification of sample type
- Inert stainless steel construction
- Can be operated from a bridge, raft or boat.

#### Disadvantages

- Debris and pebbles in the sediment may affect sample retention
- Uneven sample sizes
- Some deviation from the sample site if strong currents present.

#### Accessories

- Cable, if required.

#### Specifications

- 1/2 litre.

#### Alternatives

For disturbed samples an Ekman Sampler and for undisturbed samples a Multisampler or Beeker Sampler can be used.