



QUICK START GUIDE:
WTW pH Data Logger

This guide serves as a quick reference for operating a WTW pH Data Logger. It is for your convenience & not intended to replace the full-length manual where additional information may be found.



The WTW pH Data Logger is supplied with one of the following programming options:

1. The unit will start automatically at a specified time.
2. The unit is programmed to start on the button.

If you are unsure how the unit was set-up for you please call us on 01428 661 660 to confirm.

To start

To prepare the unit for deploying unscrew the probe guard.

Carefully remove the rubber boot containing storage solution.

Carefully replace metal guard - probe assembly is made of glass so handle with care.

To start from the button

Unscrew end hanging cap, press button once & watch for the LED one second flash.

Wait a moment & press button again. A faster flash should be seen. The unit is now logging.

Replace the hanging cap.

Securely tie your cable or dyneema to the supplied hanging eyelet & slowly lower logger into position.

To finish

Make a note of the retrieval time & slowly lift out the logger.

Remove cable & probe guard. Refit the rubber cap with a few drops of storage solution. If no solution is available use a few drops of pH4 or tap water, never leave dry.

Refit the guard & return the unit to Van Walt for retrieval of CSV data.