

QUICK START GUIDE: MiniRae 3000



This guide is meant to serve as a quick reference for operating the MiniRae 3000 PID.

It is for your convenience and is not intended to replace the information found in the Operations Manual provided.

Operation

1. Attach water trap filter to the inlet probe attached to meter. This removes humidity from the sample stream.
WARNING: Using without water trap will allow contamination of sensor/lamp and will 'spike' the readings.
2. Turn unit on by pressing the MODE key for one second. Meter will automatically start measuring.
3. To stop taking measurements and turn the PID off, press and hold MODE key for 5 seconds.

****Please note that the Isobutylene gas is primarily provided for bump tests - If you want to calibrate in the field we recommend that you call us first.**

Calibration

1. With meter 'On' press N/- key and MODE key simultaneously until the "Password" appears. Press 'Enter' (mode button).
2. Zero Calib and Span Calib are shown. Select the calibration you require using the N/- button, press select (y/+) to select this option.
3. Follow the calibration instructions on screen.